

BORGESON

Steering You Forward

#800336 Ford FE 390/428 P/S Pump Kit

Installation notes:

- 1) This pump kit set includes 2 short spacers and 2 long spacers. Cars ***without*** A/C will need to use both the short and long spacers. Cars ***with*** A/C will only need the 2 long spacers.

Installation:

- 1) Attach the pump bracket and pulley kit to the driver's side cylinder head as shown with the included two bolts, washers and the proper amount of spacers for your application.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com