

BORGESON

Steering You Forward

#802412 Small Block Mopar (LA) V-8 P/S Pump Bracket

Installation:

****NOTE** This bracket requires use if a Saginaw self-contained power steering pump with two mounting location on the back of the reservoir.**

- 1) Attach your power steering pump to the bracket with either the 3/8 or M10 bolts depending on the power steering pump you are using. The bracket mounts to the back of the P/S pump. You will need to remove any existing mounting studs for installation.
- 2) Remove the two lower timing cover bolts and attach the power steering pump and bracket to the driver's side of the engine block with the spacers and bolts provided as shown in the picture below. Please note that these bolts are into the water jacket of the engine and coolant will escape when removing and installing the bolts.



Borgeson Universal Co., Inc.
9 Krieger Dr. Travelers Rest, SC 29690
www.borgeson.com