

<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Buick	Apollo	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Apollo	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Apollo	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Centurion	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Centurion	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Centurion	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1977	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1978	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1979	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1980	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Century	1981	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Commercial Chassis	1991	12:1 Quick Ratio Steering Box	
Buick	Commercial Chassis	1992	12:1 Quick Ratio Steering Box	
Buick	Electra	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1977	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1978	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1979	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1980	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1981	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1982	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1983	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1984	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1985	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1986	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1988	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Electra	1989	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012

Buick	Estate Wagon	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1977	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Estate Wagon	1978	12:1 Quick Ratio Steering Box	
Buick	Estate Wagon	1979	12:1 Quick Ratio Steering Box	
Buick	Estate Wagon	1980	12:1 Quick Ratio Steering Box	
Buick	Estate Wagon	1981	12:1 Quick Ratio Steering Box	
Buick	Estate Wagon	1982	12:1 Quick Ratio Steering Box	
Buick	Estate Wagon	1983	12:1 Quick Ratio Steering Box	
Buick	Gran Sport	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Gran Sport	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Gran Sport	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 350	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 350	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 400	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 400	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 455	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 455	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	GS 455	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1977	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	LeSabre	1978	12:1 Quick Ratio Steering Box	

Buick	LeSabre	1979	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1980	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1981	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1982	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1983	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1984	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1985	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1988	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1989	12:1 Quick Ratio Steering Box	
Buick	LeSabre	1990	12:1 Quick Ratio Steering Box	
Buick	Regal	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Regal	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Regal	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Regal	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Regal	1977	12:1 Quick Ratio Steering Box	
Buick	Regal	1978	12:1 Quick Ratio Steering Box	
Buick	Regal	1979	12:1 Quick Ratio Steering Box	
Buick	Regal	1980	12:1 Quick Ratio Steering Box	
Buick	Regal	1981	12:1 Quick Ratio Steering Box	
Buick	Regal	1982	12:1 Quick Ratio Steering Box	
Buick	Regal	1983	12:1 Quick Ratio Steering Box	
Buick	Regal	1984	12:1 Quick Ratio Steering Box	
Buick	Regal	1985	12:1 Quick Ratio Steering Box	
Buick	Regal	1986	12:1 Quick Ratio Steering Box	
Buick	Regal	1987	12:1 Quick Ratio Steering Box	
Buick	Riviera	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Riviera	1977	12:1 Quick Ratio Steering Box	
Buick	Riviera	1978	12:1 Quick Ratio Steering Box	
Buick	Roadmaster	1991	12:1 Quick Ratio Steering Box	
Buick	Roadmaster	1992	12:1 Quick Ratio Steering Box	
Buick	Skyhawk	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012

Buick	Skyhawk	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skyhawk	1977	12:1 Quick Ratio Steering Box	
Buick	Skyhawk	1978	12:1 Quick Ratio Steering Box	
Buick	Skyhawk	1979	12:1 Quick Ratio Steering Box	
Buick	Skyhawk	1980	12:1 Quick Ratio Steering Box	
Buick	Skylark	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Skylark	1977	12:1 Quick Ratio Steering Box	
Buick	Skylark	1978	12:1 Quick Ratio Steering Box	
Buick	Skylark	1979	12:1 Quick Ratio Steering Box	
Buick	Special	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Special	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Special	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Special	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Special	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Special	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Sportwagon	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Buick	Wildcat	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Cadillac	Brougham	1987	12:1 Quick Ratio Steering Box	





Cadillac	Fleetwood	1981	12:1 Quick Ratio Steering Box	
Cadillac	Fleetwood	1982	12:1 Quick Ratio Steering Box	
Cadillac	Fleetwood	1983	12:1 Quick Ratio Steering Box	
Cadillac	Fleetwood	1984	12:1 Quick Ratio Steering Box	
Cadillac	Fleetwood	1985	12:1 Quick Ratio Steering Box	
Cadillac	Fleetwood	1986	12:1 Quick Ratio Steering Box	
Cadillac	Series 60 Fleetwood	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Cadillac	Series 62	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Cadillac	Series 75 Fleetwood	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Cadillac	Seville	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Cadillac	Seville	1977	12:1 Quick Ratio Steering Box	
Cadillac	Seville	1978	12:1 Quick Ratio Steering Box	
Cadillac	Seville	1979	12:1 Quick Ratio Steering Box	
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Chevrolet	Bel Air	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Bel Air	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Biscayne	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Brookwood	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Brookwood	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Brookwood	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Brookwood	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Camaro	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012





Chevrolet	Laguna	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Laguna	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Laguna	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Laguna	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Malibu	1977	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1978	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1979	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1980	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1981	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1982	12:1 Quick Ratio Steering Box	
Chevrolet	Malibu	1983	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monte Carlo	1977	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1978	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1979	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1980	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1981	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1982	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1983	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1984	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1985	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1986	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1987	12:1 Quick Ratio Steering Box	
Chevrolet	Monte Carlo	1988	12:1 Quick Ratio Steering Box	
Chevrolet	Monza	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monza	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Monza	1977	12:1 Quick Ratio Steering Box	
Chevrolet	Monza	1978	12:1 Quick Ratio Steering Box	
Chevrolet	Monza	1979	12:1 Quick Ratio Steering Box	

Chevrolet	Monza	1980	12:1 Quick Ratio Steering Box	
Chevrolet	Nova	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Nova	1977	12:1 Quick Ratio Steering Box	
Chevrolet	Nova	1978	12:1 Quick Ratio Steering Box	
Chevrolet	Nova	1979	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1982	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1983	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1984	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1985	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1986	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1987	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1988	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1989	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1990	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1991	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1992	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1993	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1994	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1995	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1996	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1997	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1998	12:1 Quick Ratio Steering Box	
Chevrolet	S10	1999	12:1 Quick Ratio Steering Box	
Chevrolet	S10	2000	12:1 Quick Ratio Steering Box	
Chevrolet	S10	2001	12:1 Quick Ratio Steering Box	
Chevrolet	S10	2002	12:1 Quick Ratio Steering Box	
Chevrolet	Townsmen	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Townsmen	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Townsmen	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Townsmen	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Chevrolet	Vega	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012

Chevrolet	Vega	1977	12:1 Quick Ratio Steering Box	
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
GMC	S15	1982	12:1 Quick Ratio Steering Box	
GMC	S15	1983	12:1 Quick Ratio Steering Box	
GMC	S15	1984	12:1 Quick Ratio Steering Box	
GMC	S15	1985	12:1 Quick Ratio Steering Box	
GMC	S15	1986	12:1 Quick Ratio Steering Box	
GMC	S15	1987	12:1 Quick Ratio Steering Box	
GMC	S15	1988	12:1 Quick Ratio Steering Box	
GMC	S15	1989	12:1 Quick Ratio Steering Box	
GMC	S15	1990	12:1 Quick Ratio Steering Box	
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Jeep	Wrangler	1987	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1987	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1988	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1988	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1989	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1989	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1990	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1990	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1991	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1991	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1992	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1992	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1993	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1993	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1994	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1994	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1995	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1995	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1997	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1998	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	1999	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	2000	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	2001	12:1 Quick Ratio Steering Box	
Jeep	Wrangler	2002	12:1 Quick Ratio Steering Box	
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Oldsmobile	442	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	442	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	442	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	442	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	442	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	442	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012



Oldsmobile	Custom Cruiser	1991	12:1 Quick Ratio Steering Box	
Oldsmobile	Custom Cruiser	1992	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass	1977	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass	1978	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass	1979	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass	1980	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass	1981	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1978	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1979	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1980	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1981	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1982	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1983	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Calais	1984	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Cruiser	1980	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Cruiser	1981	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Cruiser	1982	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Cruiser	1983	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass Salon	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass Salon	1977	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1978	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1979	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1980	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1985	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1986	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Salon	1987	12:1 Quick Ratio Steering Box	
Oldsmobile	Cutlass Supreme	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass Supreme	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Cutlass Supreme	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012



Oldsmobile	Dynamic	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Dynamic	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Dynamic	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	F85	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Fiesta	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Jetstar 88	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Jetstar 88	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Jetstar 88	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Jetstar I	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Jetstar I	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Omega	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Omega	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Omega	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Omega	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Omega	1977	12:1 Quick Ratio Steering Box	
Oldsmobile	Omega	1978	12:1 Quick Ratio Steering Box	
Oldsmobile	Omega	1979	12:1 Quick Ratio Steering Box	
Oldsmobile	Starfire	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Starfire	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Starfire	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Starfire	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Starfire	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Starfire	1977	12:1 Quick Ratio Steering Box	
Oldsmobile	Starfire	1978	12:1 Quick Ratio Steering Box	
Oldsmobile	Starfire	1979	12:1 Quick Ratio Steering Box	
Oldsmobile	Starfire	1980	12:1 Quick Ratio Steering Box	
Oldsmobile	Super 88	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Toronado	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012

Oldsmobile	Toronado	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Oldsmobile	Vista Cruiser	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
<b>Make</b>	<b>Model</b>	<b>Year</b>	<b>Product</b>	<b>Application Notes</b>
Pontiac	Acadian	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Acadian	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Acadian	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Acadian	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Astre	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Astre	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Astre	1977	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Bonneville	1977	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1978	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1979	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1980	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1981	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1982	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1983	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1984	12:1 Quick Ratio Steering Box	
Pontiac	Bonneville	1985	12:1 Quick Ratio Steering Box	



Pontiac	Firebird	1986	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1987	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1988	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1989	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1990	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1991	12:1 Quick Ratio Steering Box	
Pontiac	Firebird	1992	12:1 Quick Ratio Steering Box	
Pontiac	Grand Am	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Am	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Am	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Am	1978	12:1 Quick Ratio Steering Box	
Pontiac	Grand Am	1979	12:1 Quick Ratio Steering Box	
Pontiac	Grand Am	1980	12:1 Quick Ratio Steering Box	
Pontiac	Grand LeMans	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand LeMans	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand LeMans	1977	12:1 Quick Ratio Steering Box	
Pontiac	Grand LeMans	1978	12:1 Quick Ratio Steering Box	
Pontiac	Grand LeMans	1979	12:1 Quick Ratio Steering Box	
Pontiac	Grand LeMans	1980	12:1 Quick Ratio Steering Box	
Pontiac	Grand LeMans	1981	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Prix	1977	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1978	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1979	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1980	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1981	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1982	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1983	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1984	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1985	12:1 Quick Ratio Steering Box	
Pontiac	Grand Prix	1986	12:1 Quick Ratio Steering Box	

Pontiac	Grand Prix	1987	12:1 Quick Ratio Steering Box	
Pontiac	Grand Safari	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grand Safari	1977	12:1 Quick Ratio Steering Box	
Pontiac	Grand Safari	1978	12:1 Quick Ratio Steering Box	
Pontiac	Grandville	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grandville	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grandville	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grandville	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Grandville	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	GTO	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	LeMans	1977	12:1 Quick Ratio Steering Box	
Pontiac	LeMans	1978	12:1 Quick Ratio Steering Box	
Pontiac	LeMans	1979	12:1 Quick Ratio Steering Box	
Pontiac	LeMans	1980	12:1 Quick Ratio Steering Box	
Pontiac	LeMans	1981	12:1 Quick Ratio Steering Box	
Pontiac	Parisienne	1983	12:1 Quick Ratio Steering Box	

Pontiac	Parisienne	1984	12:1 Quick Ratio Steering Box	
Pontiac	Parisienne	1985	12:1 Quick Ratio Steering Box	
Pontiac	Parisienne	1986	12:1 Quick Ratio Steering Box	
Pontiac	Phoenix	1977	12:1 Quick Ratio Steering Box	
Pontiac	Phoenix	1978	12:1 Quick Ratio Steering Box	
Pontiac	Phoenix	1979	12:1 Quick Ratio Steering Box	
Pontiac	Safari	1987	12:1 Quick Ratio Steering Box	
Pontiac	Safari	1988	12:1 Quick Ratio Steering Box	
Pontiac	Safari	1989	12:1 Quick Ratio Steering Box	
Pontiac	Star Chief	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Star Chief	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Star Chief	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Sunbird	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Sunbird	1977	12:1 Quick Ratio Steering Box	
Pontiac	Sunbird	1978	12:1 Quick Ratio Steering Box	
Pontiac	Sunbird	1979	12:1 Quick Ratio Steering Box	
Pontiac	Sunbird	1980	12:1 Quick Ratio Steering Box	
Pontiac	Tempest	1964	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1965	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1966	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1967	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1968	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1969	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Tempest	1970	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1971	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1972	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1973	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1974	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1975	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1976	12:1 Quick Ratio Steering Box	Requires Rag Joint #990012
Pontiac	Ventura	1977	12:1 Quick Ratio Steering Box	