

# **BORGESON**

**Steering You Forward**

## #802410 Ford I-6 200/250 P/S Pump Bracket

### Installation:

- 1) Attach the bracket to the driver's side mounting pad on the engine block with the two 5/16" bolts and washers.
- 2) Attach the P/S pump to the front of the bracket with either the 3/8" or M10 bolts depending on the P/S pump you are using.



Borgeson Universal Co., Inc.  
9 Krieger Dr. Travelers Rest, SC 29690  
www.borgeson.com

9/4/15

# **BORGESON**

**Steering You Forward**

## #802410 Ford I-6 200/250 P/S Pump Bracket

### Installation:

- 3) Attach the bracket to the drivers side mounting pad on the engine block with the two 5/16" bolts and washers.
- 4) Attach the P/S pump to the front of the bracket with either the 3/8" or M10 bolts depending on the P/S pump you are using.



Borgeson Universal Co., Inc.  
9 Krieger Dr. Travelers Rest, SC 29690  
www.borgeson.com

9/4/15